

CMG-40T CALIBRATION SHEET

WORKS ORDER: 3908 DATE: 11/07/07
SERIAL NUMBER: T4O31 TESTED BY: S. Goddard

	Velocity Output V/m/s	Mass Position Output (Acceleration output) V/m/s ²	Feedback Coil Constant Amp/m/s ²
VERTICAL	996	19.4	0.004135
NORTH/SOUTH	1011	19.9	0.004237
EAST/WEST	996	18.8	0.003992

Power Consumption: 60mA @ +12V input
Calibration Resistor: 51000

NOTE: A factor of 2 x must be used when the sensor outputs are used differentially (also known as push-pull or balanced output). Under no conditions should the negative outputs be connected to the signal ground. A separate signal ground pin is provided.

POLES AND ZEROS TABLE

WORKS ORDER NUMBER: 3908

SENSOR SERIAL NO: T4031

Velocity response output, Vertical Sensor:

<u>POLES (HZ)</u>	<u>ZEROS HZ</u>
$-23.65 \times 10^{-3} \pm j23.65 \times 10^{-3}$	0
$-62.3816 \pm j 135.392$	0
.350	
.75	

Normalizing factor at 1 Hz: A = 585.8×10^6

Sensor Sensitivity: See Calibration Sheet.

Velocity response output, Horizontal Sensors:

<u>POLES (HZ)</u>	<u>ZEROS (HZ)</u>
$-23.65 \times 10^{-3} \pm j23.65 \times 10^{-3}$	0
$-62.3816 \pm j 135.392$	0
.350	
.75	

Normalizing factor at 1 Hz: A = 585.8×10^6

Sensor Sensitivity: See Calibration Sheet.

NOTE: The above poles and zeros apply to the vertical and the horizontal sensors and are given in units of Hz. To convert to Radian/sec multiply each pole or zero with 2π . The normalizing factor A should also be recalculated.